


Data capture and analysis with Engduino and spreadsheets

Engduino Support Team - support@engduino.org University College London



1. Introduction

In this tutorial we are going to get an idea of how to capture data from the Engduino, in particular the accelerometer, and then perform some analysis of the data. There are many situations when you may want to collect data from an external device and then use a computer to analyse it. For example, civil engineers sometimes place devices that count vehicles and record the times they go past so that they can make decisions on how many lanes a road needs, whether it's a good idea to restrict parking, or optimise traffic light timings.

1.1. Aims

What we want to be able to do is collect data from the accelerometer and then save it to a special file that we can open in a spreadsheet. Once this is done we may analyse the information more easily so that we might draw conclusions. We will connect the Engduino and get a friend to perform a movement of some sort: running on the spot, marching on the spot, jumping in the air, or perhaps a combination of these movements. We must ensure we are unable to see them performing the movement so that we can figure out what the person did based on analyses of the data.

1.2. Equipment Needed

For this you will need:

- Engduino and a long USB extension cable.

- The python app to receive the data and any computer/Raspberry Pi that has a python environment installed. See python.org if you need to install it on your Windows machine.
- MS Excel or OpenOffice Calc.
- A friend

2. Preparation

Download the python "AccelerometerCaptha.py" app from our website (click here if you haven't downloaded it yet) and drop it on your desktop or somewhere it can easily be found. Download the SerialAccelerometer.ino from our website (click here) and upload it to your Engduino device. Refer to here if you are unsure how to do this. **IMPORTANT:** You need to install pyserial to communicate with the device. See here for instructions on how to do this.

3. A little background information

In order to understand what you are doing a little more, we are going to quickly talk about the accelerometers so we know a little bit about the data before we try to analyse it.

3.1. Accelerometers

3.1.1 What is an accelerometer?

An accelerometer is an electromechanical device that will measure acceleration forces. These forces may be static, like the constant force of gravity pulling at your feet, or they could be dynamic - caused by moving or vibrating the accelerometer. By measuring the amount of static acceleration due to gravity, you can find out the angle the device is tilted at with respect to the earth. By sensing the amount of dynamic acceleration, you can analyse the way the device is moving.[1]

3.1.2 How does the accelerometer measure gravity

An accelerometer measures the force being applied on it in three different dimensions, X, Y, and Z. Using these three dimensions and a little knowledge about vectors we can work out the acceleration in any direction in 3-dimensional space. The accelerometer on the Engduino provides these values in g . One g is equal to $\approx 9.8m.s^{-2}$ which is the force due to acceleration that is constantly being applied to us whilst standing on the earth's surface. $2g$ would be twice that number or $\approx 19.6m.s^{-2}$.




Figure 1: How the XYZ axes look to us

3.1.3 Important points

What is important to remember from all this is that your Engduino will always have a total vector force of $1g$ on it when it is at rest, like lying on a table. If we see any changes, it means something is making it move or change direction. Conversely, if it is moving at a constant velocity (speed) and not changing direction, the accelerometer will only detect the force due to gravity, i.e. the accelerometer cannot tell you when it is moving, only when it is changing direction or speed or being moved from rest.

4. Getting the data

Let's make sure everything is working. Once you've uploaded the `SerialAccelerometer.ino` to your Engduino and you're sure it's switched on, in the Arduino IDE: click on the serial monitor button as shown.




Figure 2: Activating the serial monitor

You should see a small window pop up and the Accelerometer data scrolling through in sets of three. Like this




Figure 3: The Arduino serial monitor

If you move the board around, you should see these values change. If that's all working, you are ready to start. Start up the AccelerometerCaptcha.py on your computer by double-clicking the file. You should see a window like this if you are on Windows




Figure 4: The Python Data Logger

(on Mac or Linux it will slightly different). Double check in the Arduino IDE what port number is

selected for your board by selecting **Tools**→**Board** and seeing which one is checked. In the Data Capture window select the **Device** menu and then choose the "Select your Device" option. In Windows, a popup window will appear and ask you for the COM port number. Enter it here, without the COM bit, so if your COM port is COM5 you would enter just 5. Once that's done, test the logger to see that it's communicating with the board. Hit the start button on the bottom.




Figure 5: Start login

The window in the centre of the program should show the values you saw in the Arduino Serial Monitor. If not, re-check the port number is correct and that the device is switched on.

5. Capturing your Friend's movement

Once you're all set up get your friend to hold the device in their hand (make sure you are using the extension cable) and tell them to hit start once you cannot see what they are doing. You can turn around or leave the room. Ask them to keep an eye on the window and keep moving until the message "Log Complete" appears.

6. Saving the data

The data has now been temporarily saved into a file called accell.csv. By clicking the **Save** button you can save it somewhere it can easily be found.

7. Importing the data

We now need to import the data into Excel. The procedure for OpenOffice versions is the pretty much the same, you can get in touch with us if you have any problems. Once you've opened Excel, click **File** → **Open** and select the file you just saved. Your file should be populated with three columns like this.




Figure 6: Imported Data

8. Analysing the Data

If you look at the numbers in the column you will see they are somewhere in the range of $-2 \rightarrow 2$. These represent how many g is being detected on each axis. The first column is the X axis, the second is Y and the third, Z. Looking at this each row is the values extracted at $\frac{1}{5}^{th}$ of a second intervals.

8.1. Getting the absolute value of the acceleration vector

When we add the three vectors we get a final vector in 3D space that represents the total acceleration. Like this:




Figure 7: Total vector(black) in 3D space

However, trying to see how this changes over time is difficult since one of these diagrams would have to be made for every row! Let's see if we can make it easier.

8.2. Vector magnitude

We could probably work out what was happening with the device if we just looked at the magnitude of the vector instead of worrying about its direction too. If you think about it, your friend probably won't rotate the device much in their hand while they're jumping around. So what we are most interested in is just the magnitude. We expect the total magnitude, when they are standing still with the device, to be around 1g (remember that's how much force gravity exerts on us when we are stood still). If they jump, we might expect there to be a brief moment of strong acceleration as they push themselves off the floor and then perhaps when they land there will be another. So we should see a much larger total magnitude at these times. Perhaps by looking at these spikes graphically and comparing them to one another we can try and get a picture of what our friend did.

9. Preparing the data

To get the magnitude of a vector we need to use Pythagoras' theorem a little. In 2D space we get the magnitude of a vector by calculating

$$\text{magnitude} = \sqrt{X^2 + Y^2} \quad (1)$$

Just like when we are calculating the size of the hypotenuse of a triangle by using the adjacent sides. What you may not know is this also works in three dimensions. So to calculate the total magnitude of all three vectors we simply take the square root of the sum of the squares.

$$\text{magnitude} = \sqrt{X^2 + Y^2 + Z^2} \quad (2)$$

Let's get Excel to calculate this value for us and put it in a column next to our values so we can use it later.

9.1. Excel Formula

First select the top cell to the right of the Z value like so:

Now, type the following `=SQRT(A1*A1+B1*B1+C1*C1)`. Don't forget the "=" sign!

This tells excel you want it to calculate a value. The values A1, B1 and C1 are cells and if you look carefully you should be able to see they correspond to the values to the left of the square. It will multiply (*) each value by itself, then add them up (using the + symbol) and then the function **SQRT** will substitute the square root of that calculation into the box. When you hit return, you should see a number in the box. Probably around 1, if your friend was standing still when they first pressed the "Start" button on the program window.

9.2. Copying the formula

We obviously don't want to have to keep typing this whole formula for every single line so luckily, Excel has a nifty trick. Make sure you have the box you just typed in selected. If you bring your mouse to the

This column now contains our total magnitude for each sample, but we can get rid of the extra precision. Two decimal places should be plenty. Highlight all the cells by dragging your cursor over them and then click the reduce decimal places button until you have just two decimal places per row. Great, let's graph it and see if we can make some sense of it.




Figure 10: Reducing decimal places

10. Graphical analysis

Highlight all the values in the last column and then **Insert** → **Line Chart**. Excel will create a chart that shows something like this (if your friend did their job correctly!)




Figure 11: Graph of magnitude over time

So lets take a look at our graph. Make it as big as your screen will allow by dragging the bottom right or top right corner of the containing box so we can see what's happening. On the bottom axis we see the sample number. Remember, each sample is taken at $\frac{1}{5}^{th}$ of a second, so every 5 samples is one second of time. The vertical axis shows us the magnitude. As you can see, just after our friend pressed the "Start" button to begin logging he was still stood still and so our graph shows a total magnitude of $1g$. Then later on at some point, the acceleration went all the way past $2g$. Let's zoom in on this area of interest for a moment.



Figure 12: Zoomed in on the area of interest

I've indicated this first event with the red arrows. So at some point the magnitude of the acceleration went all the way past $2g$ and then went all the way down to almost 0, then a short time after that went back up to 2 and then settled near 1 for a while. What do you think this could mean?

Think about it for a moment.

Keep this picture of the different stages of a human jump in mind for reference.



Figure 13: Stages of a human jumping over time

When we first bend down getting ready to jump, we move with gravity a little, so the force on us is slightly lower. This explains the first tiny dip.



Figure 14:

Then we push off with our legs we create a strong force of acceleration. This explains the first spike.



Figure 15: Jump

As we near the top of a jump, for an instant we are stationary, so the value of the acceleration goes to...? Well done if you said 1! Remember when we are stationary on the earth's surface, **or the air**, gravity exerts a force of $1g$ on us. So it goes to 1 here.



Figure 16: Stationary in the air

But, it doesn't stop going down because as soon as we're stationary we start moving back down towards the ground. In free fall we are moving almost entirely with the force of gravity, so our accelerometer registers a total magnitude of nearly 0.



Figure 17: Free-falling to ground

Once we hit the ground, there is a sharp and strong acceleration that stops us from moving (from the ground) and then it settles back to 1 for some time while we are stood still. In my example you can see 5 similar patterns except they start becoming smaller. So, maybe my friend jumped high the first time, then jumped as soon as he hit the ground again, then he rested for a moment and did another two jumps and then moved only slightly and then did a little jump. What did your friend do? Ask them, and see how well you did.

11. Your own experiment

To get an idea of how different movements appear on your graph, get your friend to first take two steps on the spot. Then wait a second, and do a small jump, and then wait a few seconds and do a jump as high as he can. Follow the steps above and create your graph in a new file. Keep this file open and use it as a reference when you analyse some movements you didn't see. Swap positions and see how your friend compares to you.

11. References

- [1] A beginners guide to accelerometers, <http://www.dimensionengineering.com/info/accelerometers>.
Dimension Engineering LLC